

Radio Catalog
Sunday – October 3, 2010 – 10:00 AM
Collectors Hall – 135 West Center St. – Cambridge, IL.
Doors Open At 7:30 am the day of the auction

301. 1946 Belmont, mod. 5D 128 ?, plastic, 5 push buttons, 2 knobs, radio
302. 1920s Remler type 330, control panel
303. 1938 Majestic Charlie McCarthy w/figure, dark plastic case (as is)
304. 1938 RCA mod. 978-5 “Little Nipper” Catalin green onyx, **Rare** radio
305. 1928 Philco metal round speaker for rectangular radio
306. 1920s Horn design radio speaker
307. 1920s Tower Mfg. Co. horn design radio speaker “Little Spitfire”
308. 1920s Music Master, horn design radio speaker
309. 1920s General Radio Corp., horn design radio speaker
310. 1920s RCA mod. 100-A metal Loudspeaker
311. 1920s Kuzen ? wood case rectangular low radio
312. 1940s Crosley, wood case, mod. 56T table top radio
313. 1940s Utah, wood case, Loudspeaker
314. 1924 Crosley, wood case, mod. 52SD, Spl. Deluxe, high rectangular radio
315. 1920s ? , wood case, low rectangular, 4 knobs, radio, as is
316. 1949 GE, plastic case, mod. 66, left alarm clock radio
317. 1930s National Supply Co., Music Master, wood case, Loudspeaker
318. 1920s Wood case, high rectangular, 4 knobs, radio
319. 1920s RCA, model 100-B, metal case, Loudspeaker (as is)
320. 1940s Philco, mod. 40-145, wood case, Deco grill, 6 push buttons, radio
321. 1920s Atwater Kent, type E3, metal speaker
322. 1920s Quam Radio Co., metal, Loudspeaker
323. 1924 Crosley, mod. 51, wood case, low rectangular, 2 tubes, 1 dial, radio
324. 1920s Crosley, type D, metal, Loudspeaker
325. 1920s Crosley, mod. 52, wood case, low rectangular, 3 tubes, 1 dial, radio
326. 1940s ? , wood case, shortwave, 3 knobs, radio
327. 1920s Radiola Loudspeaker, mod. UZ-1325, horn style speaker
328. 1920s Kilbourne & Clark base, horn style speaker
329. 1920s FADA, mod. One-Sixty, low rectangular, 3 dial, radio
330. 1920s Victor Crystal radio
331. 1920s Crosley, mod. 52, wood case, low rectangular, 3 tubes, 1 dial, radio
332. 1920s Airline Dynamic, metal, Loudspeaker
333. 1920s ? , horn design speaker
334. 1940s ? Belmont or Freshman Prod., wood case, Cathedral style, radio
335. 1930s Silvertone, wood case, Tombstone, round dial, 4 knobs, radio
336. 1947 True Tone, mod. D2634, wood case, 3 knobs, slide rule dial, radio
337. 1920s Temple, metal frame, radio Loudspeaker
338. 1924 Crosley, mod. 51, wood case, low rectangular, 2 tubes, 1 dial, radio
339. 1920s ? , wood case, low rectangular, 4 tube, 3 dial, radio
340. 1950s Zenith, mod. J508B, plastic case, round dial, radio
341. 1954 Motorola, mod. 53X1, plastic case, half moon dial on top, radio
342. 1940s Bee-less radio, wood case, Tombstone, round dial, radio
343. 1930s Crosley, mod. 179, wood case, Tombstone, Deco style, radio
344. 1920s Atwater Kent, type E, metal frame, Loudspeaker
345. 1920s Crosley, Musicone B, metal frame, Loudspeaker
346. 1924 Crosley, mod. 51, wood case, low rectangular, 2 tube, 1 dial, radio
347. 1920s ACE, AE type V, wood case, low rectangular, 1 tube, 1 dial, radio
348. 1930s Majestic Super B current supply unit
349. 1960s Coca Cola cooler design transistor (Adv. Pc.) radio
350. 1960s U.S. Command Space Satellite “Moon Radio” No. 640, orig. box, radio
351. 1920s King Quality, wood case, high rectangular, 5 tube, 3 dial, radio
352. 1931 Crosley, “Super Buddy Boy” Cathedral, Repwood case, 3 knobs, radio

353. 1947 Silvertone, wood case, right round dial, 3 knobs, 3 horizontal bars, radio
354. 1930s Silvertone, mod. 1985, wood case, Tombstone, 4 dial, radio
355. 1946 Automatic Radio Co., mod. 614X, plastic case, Starburst dial, radio
356. 1940s Zenith, mod. ?, wood case, Deco style, half moon dial, radio
357. 1922 Westinghouse, Aeriola Sr. receiver, wood case, radio
358. 1924 Crosley, mod. 51 SD, wood case, Spl. Deluxe, high rectangular, ½ moon, radio
359. 1946 Detrola, mod. 568-13-221D, upper right slide rule dial, 3 knobs, radio
360. 1926 Atwater Kent, mod. 30, wood low rectangular case, 1 dial, radio
361. 1940s GE, mod. 123, plastic case, 2 knobs, radio
362. 1950 Emerson, mod. 642A, plastic case, 2 knobs, round dial, radio
363. 1940s Kent, mod. 422, metal case, Midget, Police Badge dial, 1 knob, radio
364. 1940s WLS Silvertone, metal frame, Deco design speaker
365. 1920s Crystal radio in wood case
366. 1935 Philco, mod. 60, wood case, Cathedral, 4 knobs, radio
367. 1941 GE, mod. J62, wood case, slide rule dial, 3 knobs, radio
368. 1930s Emerson, mod. 23, wood case, cut-out center, 2 knobs, radio
369. 1948 Crosley, mod. 58TW, plastic case, Lucite handle, 2 knobs, radio
370. 1920s unusual homemade or Kit Crystal radio
371. 1920s Crystal radio
372. 1920s Steinite Crystal radio in orig. box
373. 1925 Zenith wood battery box for radio (**rare**)
374. 1946 GE, mod. 203, wood case, rectangular dial, 2 knobs, radio
375. 1960s Classic Juke box radio (NIB)
376. 1920s Akrodyne, wood case, high rectangular, 5 tube, 3 knobs, radio
377. 1937 Philco, mod. 37-84, wood case, Cathedral, 2 knobs, radio
378. 1940s Philco, mod. 40-150, wood case, 8 push buttons, 4 knobs, radio
379. 1930s MW, mod. 62177, wood case, Tombstone, round dial, 4 knobs, radio
380. 1928 Atwater Kent, metal case, low rectangular, left front dial, radio
381. 1927 Atwater Kent, metal case, low rectangular, left front dial, radio
382. 1946 Zenith, mod. 5D027Z, tow tone wood case, Consol Tone, black dial, 1 knob, radio
383. 1924 Clapp-Eastham Co./Radak, type R-4, wood case, high rectangular, 1 tube, 2 dial, radio
384. 1923 ACE, type V, wood case, low rectangular, 1 tube, 1 dial, radio
385. 1920s Crosley, type V, wood case, low rectangular, 1 tube, 1 dial, radio
386. 1920s Crosley, type V, wood case, low rectangular, 1 tube, 1 dial, radio
387. 1930 Crosley, mod. 54G, Tombstone New Buddy, Repwood carved front panel, radio
388. 1931 Crosley, Elf, Cathedral, pressed wood case ornate “carved” front, radio
389. ? Tom Thumb portable carrying case (**rare**) radio
390. 1930s Clarion Jr., mod. 320, Tombstone wood case, 5 blue tubes, 3 knobs, radio
391. 1937 Philco, mod. 37-620, Tombstone wood case, upper round dial, **rare** radio
392. 1925 Marwol, Baby Grand, low rectangular, slanted 3 dial, 5 exposed tubes, radio
393. 1925 Federal, Orthosonic mod. A-10, wood case, low rectangular, 3 dial, 5 tube, radio
394. ? Teletone, wood frame, Loudspeaker
395. ? Peerless, wood frame, Loudspeaker
396. 1924 Crosley, mod. 51, wood case, low rectangular, 1 dial, 2 tube, radio
397. 1925 FADA, type 192-A, wood case, Neutrolette, rectangular, 3 dial, radio
398. 1920s Crystal radio
399. ? Master Vibrator model T coil
400. ? Work-Rite 180 Super Vario coupler in orig. box
401. ? Crystal radio
402. ACE Spring Suspended Microphone in orig. box
403. 1945 Westinghouse, mod. H-124, Little Jewel, refrigerator, radio
404. 1936 International Radio, mod. 66-Kadette, wood case, 3 knobs, radio
405. 1941 GE, mod. J-62, wood case, side handles, slide rule dial, 3 knobs, radio
406. 1941 Truetone, mod. D2210, metal w/wood finish, right dial, chrome trim, 2 knob, radio
407. 1933 RCA, mod. 100, wood case, Cathedral, center dial, 4 knobs, radio
408. 1940s Philco, mod. 40-135, wood case, 6 push buttons, slide rule dial, 4 knobs, radio
409. 1939 Zenith, mod. 5X230, wood case Tombstone, round black dial, 4 knobs, radio

410. 1923 Neutrodyne, wood case, low rectangular, 3 dial, radio
411. 1920s Crosley, Trirdyn, wood case only
412. 1927 RCA Radiola 60, wood, two-tone walnut, low rectangular, radio
413. 1925 Music Master, type 100, wood, low rectangular, 3 dial, stube radio
414. 1925 Freshman, mod. 5F5, mahogany, low rectangular, 3 dial., left speaker, radio
415. 1924 Atwater Kent, mod. 20, wood, Big Box, low rectangular, 3 dial, radio
416. 1927 Radiola 18, wood, low rectangular, 7 tube, 2 knob, radio
417. 1930s Aetna, mod ?, wood Tombstone, 4 knobs, Police & foreign band, radio
418. 1948 Truetone, D 3721, leatherette, front slide rule dial, plastic grill, radio
419. 1948 Detrola, 611-A ?, wood, right round dial, 4 knobs, radio (as is)
420. 1927 Arborphone, mod. ?, wood, low rectangular, 3 dials, 5 tube, radio
421. 1930s Gloritone, mod. 27, wood, Cathedral, thumbwheel dial, radio
422. 1930s Majestic V, wood, low rectangular, 3 Bakelite style dials, radio
423. 1924 Atwater Kent, mod. 42, metal case, 7 tube, low rectangular, radio
424. ? Signal Corps US Army BC-224D radio receiver
425. 1920s Atwater Kent, model B, metal frame, Loudspeaker
426. 1941 Zenith, mod. 79529, wood case, 11 push buttons, 2 knobs, radio
427. 1952 Hallicrafters, mod. 5R34A, plastic case, 3 knob, radio
428. 1939 RCA, mod. 5Q55, plastic case, lower slant dial, 2 knobs, radio
429. 1930s Atwater Kent, mod. 545, wood Tombstone, 3 knobs, round dial, radio
430. 1930s Airo-Master, mod. ?, wood, low rectangular, top speaker, drop door, radio
431. 1925 Freshman Masterpiece, wood, low rectangular, 2 dials, 3 tubes, radio
432. 1925 Crosley, Trirdyn reg. type 1121, wood low rectangular, 2 dials, 3 tubes, radio
433. 1935 Zenith, mod. 6-S-27, wood Tombstone, large round dial, 4 knobs, radio
434. ? Windsor, series 6816, leather carrying case radio
435. 1926 FADA Seven, wood low rectangular case, center front dial, radio
436. 1925 Day-Craft 7, wood low rectangular case, left built-in speaker, radio
437. 1931 Audiola, mod. 7, wood Cathedral, 3 knobs, ½ moon dial, radio
438. 1924 Crosley, mod. 52, wood low rectangular, 3 tube, 1 dial, radio
439. 1936 Crosley, mod. 517-Fiver, wood case, small Tombstone, 3 knobs, radio
440. 1920s Baker Electric Six, wood low rectangular case, 6 tubes, 2 knobs, radio
441. 1930s MW, mod. 62-177, wood Tombstone case, lg. round dial, 4 knobs, radio
442. 1935 GE, mod. A-70, wood Tombstone case, side rule dial, 4 knobs, radio
443. 1930s Universal, mod. ?, wood small Cathedral, center dial, 2 knobs, radio
444. 1948 Crosley, mod. 58TW, plastic case, slide rule dial, lute handle, 2 knob, radio
445. 1946 Sonora, mod. RBU 176, plastic case, slate slide rule dial, radio
446. 1930s Super Defiance, mod. ?, wood Cathedral case, 3 knobs, radio (as is)
447. 1950 Zenith, mod. G516W, plastic case, clock style radio
448. 1937 Philco, mod. 37-84, wood small Cathedral, round dial, 2 knob, radio
449. (2) 1930s RCA, mod. 103, Art Deco style, tapestry wood frame, Loudspeakers, radio
450. 1930s Crosley, mod. 583, wood small Tombstone, center dial, 2 knob, radio
451. 1920s Parker-McCrory Co., wood low rectangular, 3 knobs, 5 tube, radio
452. 1938 Stromberg-Carlson, mod. 320H, wood case, right front dial, 3 knobs, radio
453. 1940s RCA, MI6357B, wood case, inter-communication style radio
454. 1940s RCA, mod. ?, plastic case, 3 knobs, slide rule dial, radio
455. 1940s Skelco, mod. 579, wood case, 2 knobs, slide rule dial, radio
456. 1937 Philco, mod. 37-600, wood case, 2 knobs, round dial, radio
457. (2) 1950s Westinghouse, mod. H397T5, maroon plastic, clock, alarm, Tombstone, radio
458. 1953 Philco, mod. 53-707, wood case, lamp/radio/clock, tall rectangular, radio
459. 1940s True Tone, mod. D1015, plastic case, lg. center dial, 2 knobs, radio
460. 1940s Kadette, mod. ?, wood case, center dial, 2 knobs, radio
461. 1946 Stromberg-Carlson, mod. 1101 HW, wood case, slide rule dial, 2 knobs, radio
462. 1940s Kent, midget mod. 422, metal case, Police Badge dial, 2 knobs, radio
463. 1946 Wards Airline, mod. 64BR-150ZA, plastic case, slide rule dial, 2 knobs, radio
464. 1947 Emerson, mod. 540A, plastic case, midget, right vert. dial, 2 knobs, radio
465. 1950s Motorola, mod. ?, plastic case, suitcase style, radio (as is)
466. 1958 Arvin, mod. 950T2, plastic case, checkered grill, radio

467. 1946 Arvin, mod. 444, metal case, midget, right front dial, radio
468. 1948 Tele-Tone, mod. 166, plastic case, slide rule dial, 2 knobs, radio
469. 1940 RCA, mod. 15X, plastic case, slide rule dial w/red dote, radio
470. 1951 GE, mod. 442, plastic case, ½ moon dial, 2 knobs, radio
471. 1930 Crosley, mod. 54-70, New Buddy, Repwood, 2 knobs, radio
472. 1931 US Gloritone, mod. 99A, wood Cathedral, front half round dial, radio
473. 1939 RCA, mod. 96T7, wood, 8 push buttons, lower slide rule dial, radio (needs repair)
474. 1920s Bestone V 60, wood low rectangular, 5 tubes, 3 knobs, radio
475. 1927 Steinite, mod. 991, wood, 2 front window dials, center volt., 4 knobs, 6 tubes, radio
476. 1933 Philco, mod. 16, wood Cathedral, center front window dial, 4 knobs, radio
477. 1930s Trimm, Concert mod., wood Deco design speaker on legs
478. 1930s Balkeit Radio Co., mod. 42E, wood Tombstone, center dial, 2 knobs, radio
479. 1920s Music Master, wood slant front, 4 tube, 2 dials, radio
480. 1940s Tone Master, mod. ?, wood case, center round dial, cut-out grill, radio
481. 1940s Pacific, mod. ?, wood, lg. round dial w/sail ship, 3 knobs, radio
482. 1930s Sears Silvertone, mod. 1802A, wood Tombstone, center dial, 3 knobs, radio
483. 1926 A-C Dayton, mod. XL-25, wood, low rectangular, lift top, 5 tubes, 2 dials, radio
484. 1924 Atwater Kent, mod. 20, wood, low rectangular, lift top, 3 dials, radio
485. 1933 RCA, mod. R-28, wood, carryette, cut-outs, 3 knobs, right dial, radio
486. 1930s Jesse French, mod. G Jr., wood console, Queen Ann leg, radio
487. 1925 Radiola 25, wood, slanted front, 6 tubes, 2 thumb wheel dials, radio
488. 1939 Emerson, mod. CH-1 256 Strad, wood, violin shape, 2 knobs, radio
489. 1926 Atwater Kent, mod. 32, wood, low rectangular, 7 tubes, 1 front dial, radio
490. 1937 Zenith, mod. 6S229, wood, Tombstone, Rd. black dial, 4 knobs, radio
491. 1933 Majestic, mod. 463, Century Six, wood, w/Deco chrome cut-outs, radio
492. 1923 Michigan Radio Corp., Jr., wood, low rectangular, 1 tube, 2 dial black front, radio
493. 1930s Emerson, mod. ?, wood, lg. right dial, 3 knobs, radio
494. 1924 Crosley 51, wood, low rectangular, 2 tubes, 1 dial black front panel, radio
495. 1925 Day-Fan, 5106 OEM-7, wood, low rectangular, lift top, 4 tubes, 3 dial, radio
496. 1935 Airline, mod. 62-316, wood, off center oval dial, Deco cut-outs, radio
497. 1929 Atwater Kent, mod. 46, metal, low rectangular, lift front dial, radio
498. 1954 Zenith, mod. L520R, plastic, step-down, right front dial, lift alarm, red/black
499. 1930s Firestone, mod. S7398-1, wood, right Air Chief square dial, 2 knobs, radio
500. 1930s Rola Pedestal Re-Creator wood speaker
501. Steinite Interference Eliminator w/orig. box
502. 3 Early power switches & coil in flat
503. Lincoln Collapsible loop-antenna in orig. box
504. 2 Radiofone type 1-B Super Crystal receiving set
505. Spencer Pocket Radio in orig. box – dated 1929
506. Dated 1929 metal console radio cigarette dispenser
507. Voiso meter
508. Misc. adv. pcs. (tin containers, thermo., pencil, etc.)
509. Philmore Pocket Radio in orig. box
510. 1919 Crosley Crystal detector
511. Flat of misc. radio condensers, lightning arrester, etc.
512. Welch's Trans. AM/FM radio (NIB)
513. Radiofone type 1-B Super Crystal receiving set
514. Radiotron, mod. UV201A detector & amplifier in orig. box
515. Telegraph Key
516. Flat of 3 earphone sets
517. Flat of 3 earphone sets
518. Flat of informational paper items
519. Mod. 240 multiaapter, Eveready Tester, etc.
520. Midget Detecto-Meter & Misc. small electric switches, etc.
521. Victor adv. metal round pc.
522. Crystal radio receiver
523. Flat of 6 "The Radio Amateur's Handbooks"

- 524. 1951 Radio & TV Op. book, 1962 Radio handbook, 1943 Radio Freq. Book
- 525. Flat of 7 old Radio Informational books
- 526. Flat of 9 old Radio Informational books

- 530. 2 Flats of 43 1930s Radio News magazines
- 531. 1913 Keuffel & Esser Drawing Materials catalogue
- 532. thru 539. Flat of Radio Informational books or paper items
- 540. 1920s The Story of Kolster Radios
- 541. Flat of radio books & informational items
- 542. Flat of radio books & informational items
- 543. 10 Hawkins Electrical Guide books 1916
- 544. thru 550. Flat of radio books in informational items
- 551. thru 569. Flat of radio tubes w/orig. boxes
- 570. 5 Blue radio tubes (1) 180s, (3) 127s, (1) Sonor RA1 (choice of 5)
- 571. 3 Tungar Cat. 195528 screw in tubes
- 572. thru 580. Box of radio tubes (in various conditions)
- 581. thru 590. Flat of four earphone sets
- 591. Readrite tube tester model 430
- 592. Knight OHM's radio tester style unit
- 593. Telegraph Key unit
- 594. Readrite OHM meter tester
- 595. Western Electric OHM meter tester
- 596. Micronta OHM range double multi tester in box
- 597. Homemade crystal radio & crystal radio kit
- 598. Aetna All-Wave antenna, frost line set of earphones both in boxes
- 599. Williams & McIntosh #44 battery op. Health Shock units
- 600. Toy battery op. electric motor & telegraph style key